
Control panal face
Control panel bottom
Speaker Panel
Control panel top
Back
Bottom
Back Top
Front panel w/ coin door
Side
Top
Top / back slant